

# Finishing for oiled Berg & Berg floors

After installation we recommend a finishing with oil. The surfaces become less demanding and remarkably durable. The joints and edges receive additional protection. The finishing can be done both manually or by machine. We recommend to use a floor machine for the finish.



## Products and tools

- natural oiled products: Faxe maintenance oil natural
- white oiled products: Faxe maintenance oil white
- Oak Värmland: Faxe maintenance oil natural
- Oak Gotland: Faxe maintenance oil white
- Oak raw timber effect: Faxe InvisiOil neutral
- floor pad white or tan, padholder or floor machine
- oil absorbing cloth or feltpads.
- 1 liter of oil covers abt. 80–100 m<sup>2</sup>

## Preparation

- The surface must be clean, free of grease and dry.
- Soiled surfaces must be cleaned with Faxe intensive cleaner first. After complete drying - preferably the next day – finishing with oil can be done.

## Step by step

- Always work in segments
- Pour some oil (~50-100 ml) directly on the floor and spread it with the floor pad until the wood surface is saturated and does not absorb any more oil.
- Use the cloth or feltpad to wipe the surface completely dry. There must not remain any oily film on the surface.
- If polished with a floor machine the surface can be used after a few hours, if done by hand wait until the other day.
- Walking areas may be loosely protected the 1st day with cloth or cardboard. Do not wet wipe or wash the floor the next 4 days and keep water away.



## Safety notice

Oil soaked cloths or pads can selfignite! Soak them in water after use and spread out and let it dry outdoors.



video clip

