

Finishing for oiled Berg & Berg floors

Berg & Berg floors are treated with oxidative hardening oils at the factory. After installation, they still need to be treated with oil again. This makes the surfaces particularly hard-wearing and provides the parquet with effective edge and joint protection. It can be applied both manually and by machine. We recommend initial maintenance by machine.



Products and tools

- for natural oiled floors and Värmland:
Faxe maintenance oil plus natural
- for white oiled floors and Gotland:
Faxe maintenance oil plus white
- for raw wood oil/Österlen/Skåne:
Faxe InvisiOil
- Floor pad white or tan, padholder or floor machine
oil absorbing cloth or feltpads.
- 1 liter of oil covers abt. 80–100 m²

Preparation

- The surface must be clean, free of grease and dry.
- Soiled surfaces must be cleaned with Faxe intensive cleaner first. After complete drying - preferably the next day – finishing with oil can be done.

Step by step

- Always work in segments
- Pour some oil (~50-100 ml) directly on the floor and spread it with the floor pad until the wood surface is saturated and does not absorb any more oil.
- Use the cloth or feltpad to wipe the surface completely dry. There must not remain any oily film on the surface.
- If polished with a floor machine the surface can be used after a few hours, if done by hand wait until the other day.
- Walking areas may be loosely protected the 1st day with cloth or cardboard. Do not wet wipe or wash the floor the next 4 days and keep water away.



Safety notice

Oil soaked cloths or pads can selfignite! Soak them in water after use and spread out and let it dry outdoors.

video clip

